

# Accessories


## cutter – manually operation



For straight rectangular and burr-free cutting off the bandsaw blades

### Application:


#### AHM 025



Suitable for bandsaws up to 25 x 0,90 mm  
and steel strip/St37 up to 25 x 1,00 mm

**Machine mounted version only !**

#### AHM 040



Suitable for bandsaws up to 40 x 0,90 mm  
and steel strip/St37 up to 40 x 1,00 mm

**Machine mounted version only !**

#### AHE 050



Suitable for bandsaws up to 50 x 1,00 mm  
and steel strip/St37 up to 50 x 1,00 mm

**To be mounted on a work bench !**

#### AHE 060



Suitable for bandsaws up to 60 x 1,00 mm  
and steel strip/St37 up to 60 x 1,00 mm

**To be mounted on a work bench !**

# Accessories

cutter – manually operation



*For straight rectangular and burr-free cutting off the bandsaw blades*

**AHE 080**



## Application:

Suitable for bandsaws up to 80 x 1,65 mm  
and steel strip/St37 up to 80 x 2,50 mm

**Especially for bi-metal and alloyed steel !**


**AHE 121**



Suitable for bandsaws up to 120 x 2,00 mm  
and steel strip/St37 up to 120 x 3,50 mm

**For the professional weld shop !**

**AHE 250**



Suitable for bandsaws up to 250 x 1,65 mm  
and steel strip/St37 up to 250 x 3,00 mm

**AHE 420**



Suitable for bandsaws up to 420 x 2,50 mm  
and steel strip/St37 up to 420 x 2,50 mm

# Accessories

cutter – pneumatic operation



*For straight rectangular and burr-free  
Cutting off the bandsaw blades*


## Application:

### *APE 080*




Suitable for and bandsaws up to 80 x 1,65 mm  
and steel strip/St37 up to 80 x 1,65 mm

### *APE 121*



Suitable for and bandsaws up to 120 x 2,00 mm  
and steel strip/St37 up to 120 x 3,00 mm

### *APD 121*



Suitable for and bandsaws up to 120 x 2,00 mm  
and steel strip/St37 up to 120 x 3,00 mm